


ESSENTIA, NEOLITO, CONSOLE (TIROIRS STANDARDS/*STANDARD DRAWERS*) CUBIK, DUO, FUZION, MINI (OPTION A-146)

RETIREZ TIROIR/REMOVE DRAWER

Ouvrez le tiroir au maximum
Appuyez sur la gachette sous le tiroir, à l'endroit indiqué
Tirez


*Open the drawer as far as possible
Press the trigger under the drawer, where indicated
Pull*



AJUSTEMENT HAUTEUR/HEIGHT ADJUSTMENT

Utilisez le mecanisme pour ajuster la hauteur

Use the mecanism to adjust the height



AJUSTEMENT FAÇADE - PETIT TIROIR/DRAWER FRONT ADJUSTMENT - SMALL DRAWER

Dévissez PARTIELLEMENT les 2 vis
Ajustez horizontalement et verticalement
Reserrez

*Partially unscrew the 2 screws
Adjust horizontally and vertically
Tighten*



ESSENTIA, NEOLITO, CONSOLE (TIROIRS STANDARDS/*STANDARD DRAWERS*) CUBIK, DUO, FUZION, MINI (OPTION A-146)

AJUSTEMENT FAÇADE - GRAND TIROIR/DRAWER FRONT ADJUSTMENT - LARGE DRAWER

Dévissez PARTIELLEMENT les 4 vis
Ajustez horizontalement et verticalement
Reserrez

*Partially unscrew the 4 screws
Adjust horizontally and vertically
Tighten*



Vis de fixation
Fastening screw



Vis d'ajustement
Adjustment screw

RETIREZ FAÇADE/REMOVE DRAWER FRONT

TENIR D'UNE MAIN LA FAÇADE
Dévissez les vis

*HOLD THE FRONT PANEL WITH ONE HAND
Unscrew the screws*

